# **U151F AUTOMATIC TRANSMISSION**

#### **SST**



	00045 00010	One of the first in the control of	
0000	09215-00013	Crankshaft Bearing Remover & Replacer Set B	-
Arm Open	<u> </u>		
	(09215-00471)	Camshaft Bearing Remover & Replacer	-
		Replacei	
	09223-15020	Oil Seal & Bearing Replacer	-
	09223-15030	Oil Seal & Bearing Replacer	-
	33223 10003	The search searc	
		200 120	
	09308-00010	Oil Seal Puller	-
	09350-32014	TOYOTA Automatic Transmission	-
		Tool Set	
	(09351-32010)	One-way Clutch Test Tool	-
	(33331 32313)	22 700. 700.	
	(09351-32020)	Stator Stopper	-
Ü			
	(09351-32070)	No.2 Piston Spring Compressor	-
	(09351-32140)	Oil Seal Replacer	-
	(00001-021-0)	C. Odd Ropidoo	
(C))			
	09387-00020	Direct Clutch Wrench	-
	•	•	•

	T		<u>'</u>
	09387-00030	Counter Drive Gear Holding Tool	-
	09387-00041	Bearing Puller Assembly	-
	(09387-01010)	Claw No.1	-
V	(09387-01021)	Claw No.2	-
	(3.33. 3.02.)		
	(00207 04020)	Pin	-
	(09387-01030)	ГШ	-
	(09387-01040)	Bearing Puller Body	-
	09387-00050	Under Drive Gear Puller	-
	09387-00060	Second Brake Wrench	-
	09387-00070	First & Reverse Brake Wrench	-
	09387-00080	Counter Drive Gear Nut Wrench	-
	3330, 33000	Tourist Principal	
	00500 40040	Differential Parties Parties	
	09502-12010	Differential Bearing Replacer	-
	09506-35010	Differential Drive Pinion Rear Bearing Replacer	-
		•	



09514-35011	Rear Wheel Bearing Puller	-
09527-17011	Rear Axle Shaft Bearing Remover	-
09550-60010	Differential Side Bearing Replacer	-
09564-32011	Differential Preload Adaptor	-
09608-10010	Steering Knuckle Oil Seal Replacer	-
09649-17010	Steering Knuckle Tool	-
09710-30050	Suspension Arm Bushing Replacer	-
09726-40010	Lower Control Shaft Bearing Replacer	-
09930-00010	Drive Shaft Nut Chisel	-
(09931-00010)	Handle	-
(09931-00020)	Nut Chisel	-
09950-00020	Bearing Remover	-



	09950-00030	Pooring Domovor Attachment	T
А	09930-00030	Bearing Remover Attachment	-
0			
	09950-40011	Puller B Set	-
	(09957-04010)	Attachment	-
<u></u>			
	09950-60010	Replacer Set	-
30000000000000000000000000000000000000			
- 1 P			
	(09951-00230)	Replacer 23	-
	(09951-00260)	Replacer 26	-
	(09951-00320)	Replacer 32	-
	(00054 00450)	Danie and 45	
	(09951-00450)	Replacer 45	-
(9)			
	(09951-00500)	Replacer 50	-
	(00001-0000)	ποριασσί σσ	
(6)			
	(09951-00590)	Replacer 59	-
	, ,		
	(09952-06010)	Adapter	-
	(09957-04010)	Attachment	-
_			
٨			

PP

			1
	09950-60020	Replacer Set No.2	-
0000			
	(09951-00680)	Replacer 68	-
(0)			
	(00054 00750)	Danlager 75	
	(09951-00750)	Replacer 75	-
	(09951-00810)	Replacer 81	-
6			
	(09951-00890)	Replacer 89	-
•			
	(09951-00910)	Replacer 91	-
6			
	(09951-01030)	Replacer 103	-
	09950-70010	Handle Set	-
	(09951-00890)	Replacer 89	-
•			
	(09951-07100)	Handle 100	
	(09951-0750)	Handle 150	-
	(09951-07200)	Handle 200	-



### **RECOMMENDED TOOLS**

	09011-12301	Socket Wrench 30 mm	-
	03011-12301	Gocket Wichen 30 mm	
	09031-00030	Pin Punch	-
75			
· · · · · · · · · · · · · · · · · · ·			
	09031-00040	Pin Punch .	-
and the second			
	09040-00011	Hexagon Wrench Set	-
	00040 00011	Trexagen Wienen Get	
- 0 Cm			
	(09043-20050)	Socket Hexagon Wrench 5	-
	(09043-20060)	Socket Hexagon Wrench 6	-
	(09043-20100)	Socket Hexagon Wrench 10	1-
	(09043-20100)	Socket Hexagon Wiench To	
الرائي			
	09070-20010	Moulding Remover	-
	09090-04020	Engine Sling Device	-
1 76			
d A			
	09905-00012	Snap Ring No.1 Expander	-
	00000-00012	Chap rang No. 1 Expander	
	09905-00013	Snap Ring Pliers	-
504			



## **EQUIPMENT**

Straight edge	
Torque wrench	
Vernier calipers	
Dial indicator with magnetic base	
Slide calipers	
Chain block	
Feeler gauge	
Plastic hammer	
Press	



#### **LUBRICANT**

#### Automatic transaxle fluid

Dry fill	8.1 liter (8.6 US qts, 7.1 Imp.qts)	Toyota Genuine ATF WS
Drain and refill	3.6 liter (3.8 US qts, 3.2 Imp.qts)	Toyota Gorianio 7111 VVG



## SSM

Toyota Genuine Seal Packing 1281 Three Bond 1281 or Equivalent	-
Toyota Genuine Adhesive 1344 Three Bond 1344 or Equivalent	-

